

3-Stage


26 Pin Drawer Connector

Parts available from Newark
214-458-2528

24 pin - 81F133
26 pin - 89F567
Color Coded Planar Ribbon
Cable - 81F5065WA 100'

Note:

The 24 pin connector plugs
into the bottom plug inside
each drawer. The top plug is
for the house lights and
curtain control board plug.



Drawing by:
Tim Snelling
1-15-98